

RS-232C level converter

LVC-232C

USER' S MANUAL

Ver. 1.00

DIGITAL SIGNAL TECHNOLOGY, INC.

1-7-30, Higashi Benzai, Asaka

Saitama, 351-0022, Japan

TEL 81-48-468-6094

FAX 81-48-468-6210

<http://www.dst.co.jp/en>

CONTENTS

- Function Description3
- Contents of the package3
- Electric specification3
- Environmental condition3
- Dimensions3
- How to connect4

■ Function description

LVC-232C is a RS-232C communication board for JFIL-200M when being connected with PC.

■ Contents of the package

- LVC-232C x1
- Communication cable × 1
- Power supply cable × 2

- User's Manual × 1

■ Electric specification

- | | |
|------------------------|---|
| • Function | C-MOS3.3V -- RS-232C level convert |
| • Power supply/current | 5V~7V 0.1A |
| • Connector | RS-232C side D-sub9pin female
JFIL-200M side 6pin header |


■ Environmental condition

- | | |
|-------------------------------|-------------|
| • Operating temperature range | 0°C ~ +50°C |
|-------------------------------|-------------|

■ Dimensions

W50 × H15 × D50 (mm) (except protuberance)

■ How to connect



- Descriptions of this manual are subject to change without notice.
- No portion of this manual can be reproduced without the permission of DS Technology, Inc.
- DS Technology Inc assumes no liability for damages that may occur as a result of handling by users.
- The contents of this manual do not apply to the warranty in executing an industrial property or other rights, nor permission for the right of execution.
- DS Technology Inc assumes no responsibility for the third party's industrial property accrued from using the circuits described in this manual.